

## Quick-guide Pushback at FRA-GAT

*GAT-POSITIONS CONCERNED*

**V702, V704, V706, V708, V712, V714, V716, V718**

**V711, V713, V715, V717, V719, V721**

### FOR YOUR AND YOUR PASSENGERS SAFETY:

- **IT IS NOT ALLOWED TO WALK ACROSS TXYWYs**
  - **ALL CREW MEMBERS AND PASSENGERS MUST BOARD AND REMAIN ON BOARD AT ALL TIMES (except outside-check, etc...)**
  - **IT IS NOT ALLOWED TO ANYBODY TO OPERATE THE TOWTUG, NEITHER TO TAKE A RIDE, NOR ACCOMPANY THE P/B BY FOOT.**
  - **ADHERE STRICTLY TO THE SIGNS AND INSTRUCTIONS OF THE GROUND CREW!**
1. Contact **DELIVERY** (122.035Mhz) for ENR-CLEARANCE
  2. ENG-START ONLY ACCORDING TO APRON CONTROL OR YOUR GROUND CREW
  3. Make sure, PAX and all CREW-MEMBERS are on board and you are fully ready for P/B
  4. **For P/B** contact **APRN-EAST/SOUTH** on the given FRQ by DELIVERY
  5. Contact the **PUSHBACK-DRIVER** on your **2<sup>nd</sup> COM-SET on 121.615MHz**, to coordinate the P/B and state assigned break away area
  6. Please inform the pushback driver about special features or procedures of your A/C regarding the P/B, especially STEERING, BREAKS, etc.
  7. CONDUCTION OF THE P/B:  
Your aircraft will be pushed FACE WEST into the BREAKAWAY AREA 1 or 2. Depending on your parking position, the TOWTUG-driver has to stop during the P/B and has to swap the driver's cabin. Thereafter, the P/B continues and you'll be pulled forward into to the BREAKAWAY AREA. You may expect the approval for the ENG-START from your GROUND CREW.

**Thank you very much for your understanding and cooperation.**

**We wish you a good flight! 😊**

Fraport Ground Services Executive Aviation

Tel.: +49 69 690 71719

E-Mail: [fragas@fraport.de](mailto:fragas@fraport.de)

[www.fraport-groundservices.com](http://www.fraport-groundservices.com)

26.02.2024